



8450 Cole Parkway ▪ Shawnee, KS 66227 ▪ Phone: 913-422-0707 ▪ Fax: 913-422-0808

E-mail: [onsite@biomicrobics.com](mailto:onsite@biomicrobics.com) ▪ [www.biomicrobics.com](http://www.biomicrobics.com) ▪ 800-753-FAST (3278)

### **Installation Guidelines for FAST® into IM-1060** **Adapting a FAST® 0.5, 0.625 or 0.75 System for Use in an Infiltrator IM-1060 Tank**

#### **FOR USE WITH**

(NSF Certified Std 40 & 245) MicroFAST® 0.5, 0.625, 0.75

#### **GENERAL INFORMATION**

All FAST® products are ETL certified for safety (electrical, environmental, etc.). One or more of the following patents protects this process: 3,966,599; 3,966,608; 3,972,965; 5,156,742. Certified by NSF International, the MicroFAST® 0.5, 0.625, 0.75 systems meet NSF Standard 40, Class 1 and Standard 245 certifications for single-residence wastewater treatment devices. If you have questions regarding any Bio-Microbics products, please contact us:

**800-753-FAST (3278) or (913) 422-0707**

**e-mail: [onsite@biomicrobics.com](mailto:onsite@biomicrobics.com)**

#### **Conditions:**

- A. Only persons approved by Bio-Microbics, Inc. may perform this work.
- B. An approved ISI person must perform the assembly of the tank.
- C. Once this modification is made it is NOT reversible. DO NOT perform this procedure, and then attempt to put the treatment liner back together so that it can hang from the tank lid.
- D. This method is only to be used when mounting a FAST treatment unit inside a new Infiltrator (ISI) IM-1060 single compartment tank. The ISI baffle may **NOT** be used in this tank. A separate settling tank **MUST** be still used.
- E. The FAST® Installation Manual and the Infiltrator IM-1060 Septic Tank Assembler's Resource Guide are to be used for any portions of their respective installation steps not covered here.
- F. The treatment liner is NOT designed to be a load bearing device for the tank.
- G. All other installation instructions pertaining to the installation of the treatment system are to be used.

